

Copyright Information

© 2006 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Edition 1, 4/2006

Q6504-90901

FCC Regulations

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If this equipment is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase separation between equipment and receiver.

Connect equipment to an outlet on a circuit different from that to which the receiver is located.

Consult your dealer or an experienced radio/TV technician.

Any changes or modifications to the printer that are not expressly approved by HP could void the user's authority to operate this equipment.

Use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules.

This equipment complies with FCC rules, Part 68. On the back of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company. The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all, areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

This equipment uses the following USOC jacks: RJ11C.

An FCC-compliant telephone cord and modular plug is provided with this equipment.

This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack which is Part 68 compliant. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service. If trouble is experienced with this equipment, please see the numbers in the front of this manual for repair and (or) warranty information. If the trouble is causing harm to the telephone network, the telephone company may request you remove the equipment from the network until the problem is resolved. The following repairs can be done by the customer: Replace any original equipment that came with the device. This includes the print cartridge, the supports for trays and bins, the power cord, and the telephone cord. It is recommended that the customer install an AC surge arrestor in the AC outlet to which this device is connected. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

See the electronic User Guide for more regulatory information.

Trademark Credits

Microsoft®, Windows®, is a U.S. registered trademark of Microsoft Corporation. All other devices mentioned herein may be trademarks of their respective companies.

Table of contents


1 Setting up the all-in-one

Step 1: Prepare the location.....	1
Step 2: Regulate the environment.....	1
Step 3: Verify the package contents.....	2
Step 4: Locate the all-in-one parts.....	3
Step 5: Install the control-panel overlay (if not already installed).....	4
Step 6: Install the media tray.....	5
Step 7: Install the output bin support.....	7
Step 8: Install the automatic document feeder (ADF) input tray.....	7
Step 9: Install the ADF output support.....	8
Step 10: Install the print cartridge.....	8
Step 11: Connect the power cord.....	10
Step 12: Connect a printer cable to the all-in-one.....	10
Step 13: Connect to a telephone line.....	11
Step 14: Turn on the all-in-one.....	11
Step 15: Set the control-panel display language and location (if necessary).....	12
Step 16: Test the hardware setup by printing a configuration report.....	12
Step 17: Test the copier by using the automatic document feeder (ADF).....	13
Step 18: Complete the hardware setup.....	13
Step 19: Connect to a Windows computer (Windows only).....	14
Step 20: Connect to a Macintosh computer (Mac OS X V10.3 and 10.4 only).....	15
Step 21: Fax setup.....	16
Step 22: Test the software installation.....	17
Step 23: Register the all-in-one.....	17
Step 24: Program the Scan To button (Windows only).....	17
Step 25: Use the HP ToolboxFX software to set device settings (Windows only).....	17
Step 26: Support information.....	18
Congratulations!.....	18
Tips for using the all-in-one.....	18
Preventing streaks and spots on scans and copies.....	18
Clearing print jams.....	19

1 Setting up the all-in-one


Step 1: Prepare the location

Place the all-in-one on a sturdy, level surface in a well-ventilated area. Make sure that the air vents are not blocked and all doors can open freely.




Step 2: Regulate the environment


Do not place the all-in-one in direct sunlight or in an area that has abrupt temperature and humidity changes. The recommended ranges are 15 to 32.5°C (59 to 90.5°F) and 10 to 80% relative humidity.




Step 3: Verify the package contents



Step 4: Locate the all-in-one parts




1	tray 1
2	priority input slot
3	output bin
4	automatic document feeder (ADF) output bin
5	automatic document feeder (ADF) input tray
6	control panel
7	cartridge-door release



8	interface ports
9	security-lock slot
10	power switch
11	power connector


Step 5: Install the control-panel overlay (if not already installed)

1. Remove the adhesive backing from the overlay.
2. Align the bottom of the overlay with the bottom of the control panel, and make sure that the holes in the overlay align with the keys on the all-in-one.
3. Press the overlay from the bottom up toward the top until it is completely attached to the all-in-one.



NOTE Make sure that the overlay is aligned correctly and is not pressing any buttons.


The control panel includes the following areas:




1	fax controls
2	alphanumeric buttons
3	display and menu controls
4	copy controls
5	scan controls

Step 6: Install the media tray


1. Remove any shipping tape from the inside and outside of the tray.
2. Slide the tray in until it fits securely.



3. Open the top of the media input tray.
4. Slide out the media guides.
5. Pull out the long-media support.



6. Place the media in the tray, and then adjust the media guides until they are flush with the media.




NOTE Do not fan the media before placing it in the tray.

7. Close the top of the media input tray.


Step 7: Install the output bin support

Insert the pin on one side of the support into the hole in the all-in-one. Flex the pin on the other side inward, and insert it into the hole.




Step 8: Install the automatic document feeder (ADF) input tray

1. Align the two tabs on the input tray with the two grooves in the ADF lid.
2. Slide the tray into the grooves until the tray snaps into place.




Step 9: Install the ADF output support

Insert the pin on one side of the support into the hole in the all-in-one. Flex the pin on the other side inward, and insert it into the hole.




Step 10: Install the print cartridge


1. Press the cartridge-door release to open the print-cartridge door.



2. Remove the print cartridge from its packaging, and then rock the cartridge gently five or six times.
3. Bend the plastic tab at the end of the cartridge.
4. Pull the tab until all the sealing tape is removed from the cartridge.



5. Hold the print cartridge by the handle and insert it into the all-in-one.



6. Close the print-cartridge door.




CAUTION If toner gets on your clothing, wipe the toner off with a clean cloth, wash the items in cold water, and air dry. Hot water or heat from a dryer sets the toner in the fabric.



NOTE Hewlett-Packard Company cannot recommend using non-HP print cartridges, whether they are new, refilled, or remanufactured. Because they are not HP products, HP cannot influence their design or control their quality.

Step 11: Connect the power cord

1. Connect the power cord to the power connector on the back of the all-in-one.
2. Connect the other end of the power cord to a grounded alternating current (AC) outlet.



NOTE Use only the power cord that came with the all-in-one.

Step 12: Connect a printer cable to the all-in-one




NOTE If you are using the all-in-one as a standalone fax machine, go to step 14. If you are using it as a standalone copier, go to step 15.

Connect the USB cable (A/B) cable to the correct port.



CAUTION Do not connect the cable to a computer at this time.




Step 13: Connect to a telephone line



NOTE If you are not using the fax functionality, go to step 15.

1. Connect the included fax cord to the port on the all-in-one that is marked with an "L".




2. Connect the cord to a telephone jack.



NOTE Use only the fax cord that came with the all-in-one. For more information about faxing, see the online User Guide.

Step 14: Turn on the all-in-one

Press the power switch on the back of the all-in-one.



Hint If the all-in-one has no power and no lights are lit on the control panel, make sure that the power cord is attached securely to both the all-in-one and a power outlet. Also, if the power cord is connected to a power strip, make sure that the power strip is switched on, or connect the all-in-one directly to a wall outlet to test the power strip.

Step 15: Set the control-panel display language and location (if necessary)

If prompted by the control panel, select your language and location. Follow the instructions on the control panel.



NOTE The all-in-one automatically restarts after you select the location.

Step 16: Test the hardware setup by printing a configuration report


1. Press **Menu**.
2. Use the < or the > button to select **Reports**, and then press ✓.
3. Use the < or the > button to select **Config report**, and then press ✓.



Hint If the page that prints is totally blank, remove the print cartridge, make sure that the sealing tape is removed (see step 10), reinstall the print cartridge, and then try printing the page again.

Step 17: Test the copier by using the automatic document feeder (ADF)

1. Load the configuration report that you just printed print-side down into the ADF input tray.
2. Adjust the media guides to sit against the page.



3. Press **Start Copy**.



Hint If the copy job produces a blank page, make sure that the original is loaded print-side up and that no jams exist in the ADF and paper path. For information about removing jams and other troubleshooting tips, see the online User Guide.

Step 18: Complete the hardware setup

If you are using the all-in-one as a standalone copier, the setup is complete. If you are using the all-in-one as a standalone fax, go to step 21 to complete the setup. To install the software, go to step 19 for Windows or step 20 for Macintosh.

Step 19: Connect to a Windows computer (Windows only)

The all-in-one software supports a full-featured installation for Windows 2000 and XP. Only print and scan functions are supported for Windows 98, Me, and Server 2003.



NOTE To connect to a Macintosh computer, go to step 20.

1. Close all programs that are running on the computer.
2. Insert the software CD-ROM into the CD drive. If the installation program does not begin automatically, click **Start**, click **Run**, click **Browse**, select the **HPSetup.exe** file on the CD, and then click **OK**.



NOTE You must have administrative privileges to install the software for Windows XP or Windows 2000.

3. Select **Install HP LaserJet software**.
4. In the Printer Connection Wizard, select a connection type.
5. The software prompts you to connect the all-in-one to a computer.
6. Follow the onscreen instructions to install the software. When prompted, select the **Typical** installation type.

Step 20: Connect to a Macintosh computer (Mac OS X V10.3 and 10.4 only)

1. Connect the USB cable (A/B) to the Macintosh.
2. Close all of the programs that are running on the computer.
3. Insert the software CD-ROM into the CD drive.
4. In the CD folder, double-click the **HP All-in-One Installer** icon.
5. Follow the onscreen instructions, and then click **Install**.
6. When prompted, restart the computer.
7. When the HP All-in-One Setup Assistant starts, follow the instructions.

Step 21: Fax setup

If you installed the all-in-one software, the HP LaserJet Fax Setup Utility (Windows) or Setup Assistant (Mac) automatically runs. The software prompts you to set the time, date and fax header. In many countries/regions, this is a legal requirement.



Hint If the utility does not run automatically, access it in the program group.

If you are using the all-in-one as a standalone fax, complete the following steps:

1. Press **Menu**.
2. Use the < or the > button to select **System Setup**, and then press ✓.
3. Use the < or the > button to select **Time/Date**. Press ✓.
4. Use the < or the > button to select the 12-hour clock or 24-hour clock, and then press ✓.
5. Use the alphanumeric buttons to enter the current time.
6. Complete one of the following:
 - For the 12-hour clock, use the < or the > button to move past the fourth character. Select **1** for a.m. or **2** for p.m. Press ✓.
 - For the 24-hour clock, press ✓.
7. Use the alphanumeric buttons to enter the current date. Use two digits to specify the month, day, and year. Press ✓.
8. Use the < or the > button to select **Fax setup**, then press ✓.
9. Use the < or the > button to select **Fax Header**, then press ✓.
10. Use the alphanumeric buttons to enter your fax number and your company name or header, and then press ✓.



NOTE The maximum number of characters for the fax number is 20; it is 40 for the company name.



NOTE For complete information about using the fax features, including how to set up fax features to work with telephone services such as voice mail, see the online User Guide.

Step 22: Test the software installation

Print a page from any program to make sure that the software is correctly installed. If the installation failed, reinstall the software. If the reinstallation fails, go to step 26.

Step 23: Register the all-in-one

Register at <http://www.register.hp.com> to receive free all-in-one updates and information that is relevant to you, including driver or software update notifications, all-in-one support alerts, and tips for using your HP all-in-one.

Step 24: Program the Scan To button (Windows only)

1. Click **Start**, click **All Programs** or **Programs**, and then click **HP**. Click **HP LaserJet 3050/3052/3055/3090 all-in-one**, and then click **Scan**.

Step 26: Support information

For customer support, see <http://www.hp.com/support/lj3050>, or see the support flyer for more information.

Congratulations!


The all-in-one is ready to use. See the online User Guide or use the HP ToolboxFX software (Windows 2000 or XP only) to solve problems.

The following sections provide tips for using the all-in-one.


Tips for using the all-in-one

Preventing streaks and spots on scans and copies

1. Unplug the all-in-one.
2. Tilt the control panel forward.
3. Clean the glass strip and white platen with a soft sponge or cloth that has been moistened with a nonabrasive cleaner.



4. Dry the glass and platen with a chamois or cellulose sponge. See the online User Guide for complete information.



© 2006 Hewlett-Packard Development Company, L.P.

www.hp.com



Q6504-90901